

SPRAY LOK 16

Detergent Resistant High Gloss Floor Finish *Capa Para Pisos De Alto Brillo Resistente Al Detergente*

This finish provides excellent protection for all types of floor coverings, such as vinyl and vinyl asbestos tile, asphalt or rubber tile, linoleum, terrazzo, concrete, sealed hardwood, etc. Extra tough polymers give it super durability, even in extreme traffic conditions.

The first thing you will notice is how smoothly it flows onto the floor surface. It spreads quickly and completely, never a problem with ridging or streaking. There's never been a floor finish with such highly developed leveling characteristics.

But ease of application is only the beginning. This floor finish will meet the most critical expectations for beauty, protection and wear. The "High Gloss" shine is virtually transparent. It enhances the beauty of your floors and it doesn't change the color. Even subtle hues stay true and the shine is bright! Due to its high level of solids, it is often possible to refinish stripped floors with less coats and still obtain a beautiful shine.

Maintenance is so easy. This floor finish can be mopped with mild detergents without harmful effects. And, heavy traffic areas can be recoated successfully.

RECOMMENDED USES:

- Resilient Floors
- Terrazzo/Hard Surfaces
- Spray Buffing Programs
- High Speed Buffing Programs
- Sealer/Finish Combination Programs

BENEFITS:

- Brilliant Gloss/Appearance
- Superb Leveling, Ease of Application
- Rapid Recoatability
- Seal and Finishes
- Clear, Non-Yellowing Film
- Easily Maintained

SPECIAL INSTRUCTIONS:

**PROTECT FROM FREEZING
KEEP OUT OF REACH OF CHILDREN**

DIRECTIONS FOR USE:

Read and understand MSDS (Material Safety Data Sheet) before using this product.

Stripping and Re-Coating Procedures:

1. Dust Mop entire area to be stripped. Remove gum labels and sticky waste with a scraper.
2. Place "Wet Floor" signs around area to be stripped.
3. Dilute recommended stripping solution according to label directions.
4. Liberally apply stripping solution to the floor. Allow product to remain on surface for 6-8 minutes.
5. Manually scrub all corners and edges that the machine can not reach.
6. Scrub the floor with a machine equipped with a pad or brush. Do Not allow stripping solution to dry onto floor. If this occurs, re-wet surface with stripping solution and scrub.
7. Pick up the stripping solution with a wet vac.
8. If a "Rinse Required" stripper was used, liberally apply clean rinse water to area just stripped. Recover with a wet pick up vacuum and proceed to Step 9. If a "Rinse Free" stripper is used proceed to Step 9.
9. Damp mop area including all corners and edges with clean water. Allow floor to air dry thoroughly.

Scrub and Re-Coating Directions:

1. Dust Mop entire area to be scrubbed. Remove gum labels and sticky waste with a scraper.
2. Place "Wet Floor" signs around area to be scrubbed.
3. Dilute recommended scrubbing solution according to label directions.
4. Liberally apply scrubbing solution to the floor. Allow product to remain on surface for 6-8 minutes.
5. Manually scrub all corners and edges that the machine can not reach.
6. Scrub the floor with a machine equipped with a pad or brush. Do Not allow scrubbing solution to dry onto floor. If this occurs, re-wet surface with stripping solution and scrub.
7. Pick up the scrubbing solution with a wet vac.
8. Damp mop area including all corners and edges with clean water. Allow floor to air dry thoroughly.

Directions for Coating with SPRAY LOK 16:

1. Presoak finish mop in clean, cold water to remove lint.
2. Pour **SPRAY LOK 16** into a clean bucket equipped with a wringer.
3. Submerge the mop into finish and wring out until drip free.
4. Frame off an area by drawing the mop in a straight line 4 inches out from all edges.
5. Fill in framed section applying finish in a figure 8 pattern. Re-wet mop as needed to apply **SPRAY LOK 16** at the rate of 2000 square feet per gallon.
6. Follow these procedures and apply first coat of **SPRAY LOK 16** to the entire floor and allow to air dry thoroughly.
7. Apply a second coat and all additional coats of finish following procedures outlined in Steps 4 thru 6. For final coat only, apply finish up to all edges and allow to dry.